

## Spare parts list

Vibrating motor A50					
No.	Count	Designation	Type	Standard	Order-Number
1	2	feather key	A8x7x12		14.80.044.06281946
2	2	centrifugal disc inside			X
3	1	washer 1 A 35-40			14.01.042.1-35-40
	1	washer 2 A 35-40			14.01.042.2-35-40
5	2	centrifugal disc outside			X
6	4	schnorr lock washer S12	S12		*)
7	4	hexagon socket head cap screw	M12x45	DIN 912	*)
8	2	o-ring A50			*)
9	2	protective hood			X
10	8	schnorr lock washer	S8		*)
11	8	hexagon socket head cap screw	M8x14	DIN 912	*)
12	1	screw connection M 20x1,5 with reduction M 25x1,5 / M20x13			14.80.002.67071179 14.80.002.67071153
13	1	rubber disc			14.80.070.0001
14	1	washer of cover of terminal box IEC80-112			*)
15	1	cover of terminal box IEC80-112			14.80.061.0000
16	4	schnorr lock washer	S5		*)
17	4	hexagon socket head cap screw	M5x12	DIN912	*)
	1	bag for electrical circuit points			**)) 14.80.000.0004
	1	component parts fuse members A50			14.80.000.00013

X depending of type of motor; Please, contact the manufacturer for product choice under specification of serial number of the motor.

\*) included in component parts fuse members

\*\*)) At delivery of the motor without connection cable a bag for electrical circuit points is included.